




The tools of innovation.

OPERATOR'S MANUAL

WELDING CARRIAGE LI'L RUNNER (HS)



801 W. Mineral Ave, Suite 103, Littleton, CO 80120

1- 303-690-9146, FAX 303-690-9172

www.steelmax.com sales@steelmax.com

Contents

1. GENERAL INFORMATION.....	3
1.1. Application	3
1.2. Technical data	4
1.3. Equipment included	5
1.4. Dimensions.....	6
1.5. Design.....	7
2. SAFETY PRECAUTIONS	8
3. STARTUP AND OPERATION.....	10
3.1. Preparing	10
3.2. Connecting to the welding circuits	12
3.3. Positioning at the work area	13
3.4. Operating	14
3.5. Changing the unit of speed.....	15
3.6. Troubleshooting	16
3.7. Maintenance	16
4. ACCESSORIES	17
4.1. Torch holders, clamps, and rods	17
4.2. Guide arms	19
4.3. 76 mm cross slide.....	22
4.4. Torch extension arm	23
4.5. Dual torch mount	24
4.6. Auxiliary magnet blocks.....	25
4.7. Flexible guide set.....	26
4.8. Guide adjustment tool.....	28
4.9. Flexible trackway set	29
4.10. Magnetic units for flexible trackway	32
4.11. Support for flexible trackway with magnetic units	36
4.12. Vacuum unit.....	36
4.13. Support for flexible trackway with vacuum units	37
4.14. Vacuum Track System.....	38
4.15. Cable anchor	38
4.16. Display protection shield	39
4.17. Fall arrester.....	39
4.18. Stainless steel wheels	40
5. EXPLODED VIEWS AND PARTS LIST	41
5.1. Li'l Runner.....	41
5.2. Li'l Runner HS.....	46
5.3. Li'l Runner 42V	51
5.4. Li'l Runner HS 42V	56
6. DECLARATION OF CONFORMITY	61
7. ENVIRONMENTAL PROTECTION.....	62
8. WARRANTY CARD	63

1. GENERAL INFORMATION

1.1. Application

The LI'L RUNNER (HS) is a welding carriage designed to make continuous butt and fillet welds. The carriage allows MIG/MAG torches and is clamped with permanent magnets.

Accessories allow using torches with a larger diameter and using two torches at the same time. They also allow the carriage to move along outside edges, lap joints and templates, walls that are low or have holes, and on ceilings, pipes, and tanks.


Using an optional flexible trackway set allows the carriage to move on a flexible rail. You can clamp the rail to the surface by using magnetic units or by using vacuum units and a vacuum track system.

The machine is designed for use by a professional operator only.

1.2. Technical data



			LI'L RUNNER HS
Voltage			1~ 115–230 V, 50–60 Hz 1~ 42 V, 50–60 Hz
Power			20 W
Welding position (according to EN ISO 6947 and AWS/ASME)	Horizontal		PA/1F/1G PB/2F PC/2G PD/4F PE/4G
	Vertical		–
Minimum path curve radius	Outer		23 5/8" (600 mm)
	Inner		21 1/2" (800 mm)
Torch type			MIG/MAG
Torch diameter			5/8–55/64"(16-22 mm)
Maximum torch reach			2 3/4" (70 mm)
Maximum allowed cable weight	Horizontal work		17.6 lbs (8 kg)
	Vertical work		–
Minimum workpiece thickness			5/32" (4 mm)
Ground clearance			5/32" (4 mm)
Horizontal pulling force			150 N
Vertical pulling force			–
Cross slide adjustment range			0–1 3/8" (0–35 mm) (up-down, left-right)
Standard guide arm adjustment range			0–6 11/16" (0–170 mm)
Horizontal speed			1 31/32-86 39/64 in/min (5–220 cm/min)
Vertical speed			–
Weight			17.6 lbs (8 kg)
Protection class			I
Protection level			IP 20
Required ambient temperature during operation			32–122°F (0–50°C)
Required ambient temperature during storage			14–158°F (-10–70°C)
Maximum allowed ambient humidity non condensing			80%

1.3. Equipment included





1	Welding carriage	1 unit
2	Torch holder	1 unit
3	Arc ignition cable	1 unit
4	4 mm hex wrench	1 unit
5	Box	1 unit
—	Operator's manual	1 unit

1.4. Dimensions



1.5. Design



2. SAFETY PRECAUTIONS

1. Before use, read this Operator's manual and complete a training in occupational health and safety.
2. Use only in applications specified in this Operator's manual.
3. Make sure that the carriage has all parts and they are genuine and not damaged.
4. Make sure that the specifications of the power source are the same as those specified on the rating plate.
5. Connect the carriage to a correctly grounded power source.
6. Do not carry the carriage by the cables, and do not pull them. This can cause damage and electric shock.
7. Keep untrained bystanders away from the carriage.
8. Before each use, ensure the correct condition of the carriage, power source, cables, plugs, sockets, control panel, and wheels.
9. Before each use, make sure that no part is cracked or loose. Make sure to maintain correct conditions that can have an effect on the operation of the carriage.
10. Keep the carriage dry. Do not expose the carriage to rain, snow, or frost.
11. Keep the work area well lit, clean, and free of obstacles.
12. Do not use near flammable materials or in explosive environments.
13. Make sure that the rubber of the wheels is clean and not damaged.
14. Do not remove the cover of the wheels.
15. Remove objects attracted to the chassis by the magnet.
16. Transport and position the carriage by using the carrying handle.
17. Put the carriage so that four wheels are on the surface. Make sure that no contact is between the surface and chassis.
18. Do not stay below the carriage that is put at heights.
19. Connect the cables only after you set the power switch to 'O'.
20. Keep the sockets clean. Do not use high pressure during cleaning.
21. Install only MIG/MAG torches whose diameter is the same as the diameter of the torch holder.
22. Do not put the torch more than 2 3/4" (70 mm) outward from the left or right side of the carriage.
23. Keep the torch cables away from the surface. Hang them to decrease the load applied on the carriage. Use only cables whose weight is not more than 17.6 lbs (8 kg) for horizontal work and 13.2 lbs (6 kg) for vertical work.

24. Do not work on curves with convex or concave radius less than specified in technical data.
25. Use the HS version of the carriage in horizontal positions only.
26. At heights, use a fall arrester not to let the carriage fall.
27. Use eye protection (helmet, shield, and screen), ear protection, gloves, and protective clothing. Do not use loose clothing.
28. Do not stop the carriage by hand. To stop, set the travel direction switch to 'O'.
29. Do the maintenance only after you unplug the carriage from the power source.
30. Repair only in a service center appointed by the seller.
31. If the carriage falls, is wet, or has any damage, stop the work and immediately send the carriage to the service center for check and repair.
32. Do not leave the carriage unattended during work.
33. If you are not going to use the carriage, remove it from the work area and keep in a safe and dry place.

3. STARTUP AND OPERATION

3.1. Preparing

Transport the carriage to the work area by the carrying handle. Set to 'O' all switches (power, direction, and arc ignition switch).




Fig. 1. View from the back

You can change the torch adjustment range to the right by $55/64"$ (22 mm). Use 4 mm hex wrench to detach the slide arm. Then, install it with four screws as shown in fig. 2.




Fig. 2. Changing the adjustment range to the right

You can change the torch adjustment range upward by $55/64"$ (22 mm). Use 4 mm hex wrench to detach the cross slide. Then, install it with four screws as shown in fig. 3.




Fig. 3. Changing the adjustment range upward

Connect the carriage to the power source. Then, put the torch into the torch holder and tighten with the knob.

3.2. Connecting to the welding circuits

The carriage can control two torches by using the arc ignition cable plugged into the arc ignition socket. To do this, refer to the diagram from fig. 4 and connect one blue-jacketed wire to one terminal of the welding circuit. Then, connect the other blue-jacketed wire to the other terminal of the same circuit. To control the second torch, connect the green-jacketed wires to the terminals of the second welding circuit.




Fig. 4. Connecting the arc ignition cable to welding circuits

Make sure that the arc ignition cable is connected correctly. To do this, turn on the power of the carriage, and then set the arc ignition switch to TEST. This should enable the arc for a while.

3.3. Positioning at the work area

Put the guide arms so that the carriage is in constant contact with the workpiece. You can set them by a constant step (interval adjustment), or continuously after you swap them (continuous adjustment). To set them correctly when the carriage moves to the left, use the 4 mm hex wrench to loosen the screw that secures the right guide arm. Next, move out the right arm about $25/64"$ (10 mm) or one groove more than the left arm (fig. 5), and then tighten the screw again.

When the carriage moves to the right, move out the left arm.




Fig. 5. Correct positioning of the guide arms

To put the carriage closer to the workpiece, use the 4 mm hex wrench to remove the roller assemblies. Next, install them at the other end of the guide arms, and then swap the guide arms (fig. 5).

Loosen the levers to adjust the position and angle of the torch. Tighten the levers after adjustment. Use two knobs at the cross slide to precisely set the torch position.

At heights, attach a fall arrester (not included) to a lug (fig. 5) to prevent fall of the carriage. This will avoid possible injury to the operator in case the carriage loses the clamping. Do not stay below the carriage that is put at heights.

3.4. Operating

To turn the carriage on, set the power switch to 'I'. All display segments come on (**8888**). Next, the software version shows (**5Ft**). If the speed unit is set to centimeters per minute, **EUR** shows. If the unit is set to inches per minute, **USA** shows. Next, the carriage speed shows. Set the required value using the speed knob.

To control the torch through the carriage, set the arc ignition switch to 'I'.



If the arc ignition switch is set to 'I', the torch starts welding immediately after you select a travel direction.

To go into the settings, press and hold the speed knob for 3 seconds. Select the parameter you want to set by turning the knob.

Parameter	Value	Description
d 1	0–5 s [step: 0.5 s]	Carriage movement delay time. When the direction switch is set to ◀ or ▶: d 1 = 0 s – the arc ignites and the carriage starts immediately, d 1 > 0 s – the arc ignites and the carriage starts after the set time (fig. 6).
d 2	0–5 s [step: 0.5 s]	Arc out delay time. When the direction switch is set to ○: d 2 = 0 s – the carriage stops and the arc goes out immediately, d 2 > 0 s – the carriage stops and the arc ignites for the set time (fig. 6).

To select the parameter, press the speed knob. Set the value by turning the knob. To set, press the knob. To exit the settings, turn the knob until *End* displays, then press and hold the knob for 3 seconds. The settings are saved and used also at the next startup of the carriage.

If the set carriage movement delay time ($d\ 1$) or arc out delay time ($d\ 2$) is more than 0 s, a parameter indicator '•' shows next to the displayed carriage speed.

Use the direction switch to select the movement direction. The carriage starts working with the set parameters (fig. 6) and speed. You can adjust the speed at any time.

To stop the carriage, set the direction switch to 'O'.




Fig. 6. Behavior of the carriage that controls the torch with the $d\ 1$ and $d\ 2$ parameters set

After the work is finished, use the power switch to turn off the carriage. Then, unplug the carriage from the power source.

3.5. Changing the unit of speed

To change the speed unit, first turn off the carriage by setting the power switch to 'O'. Then press and hold the speed knob and set the power switch to 'I' at the same time. The display shows the currently used unit. By turning the knob, go to centimeters per minute (*EUR*) or inches per minute (*USA*). To select, press the speed knob. Then the carriage turns on and displays the set speed unit.

3.6. Troubleshooting

Message	Problem	Solution
3.5.5.	Display not fully on after powering.	Contact the service center for check and repair.
EUR	Speed shown in centimeters per minute instead of inches per minute.	Refer to the section "Changing the unit of speed".
USA	Speed shown in inches per minute instead of centimeters per minute.	Refer to the section "Changing the unit of speed".
Er.5	Direction switch not set to 'O' when powering.	Set the direction switch to 'O'. If the message still shows, contact service center for check and repair.
	Shown during travel indicates a malfunction.	Contact the service center for check and repair.
Er.A	Arc ignition switch not set to 'O' when powering.	Set the arc ignition switch to 'O'. If the message still shows, contact service center for check and repair.
oC	Motor overload. The carriage stops.	Remove objects that block the carriage. Adjust the position of the cables so that they do not block the carriage. Use the welding cables whose weight is not more than the maximum weight specified in the technical data. If the message persists, contact service center for check and repair.

3.7. Maintenance

Every day:






1. Clean the chassis and wheels.
2. Clean the rollers of the guide arms. Make sure that the rollers turn freely.
3. Clean the torch nozzle and replace if damaged.







Every month:

1. Make sure that the knob and the switches work as intended. Replace if they are loose or damaged.
2. Examine cables and cords and replace if damaged.
3. Tighten screws if they are loose.

4. ACCESSORIES

4.1. Torch holders, clamps, and rods

Short rod torch holder with clamp 16–22 mm	
	Part number: UCW-0754-07-00-00-0
Quick-release short rod torch holder with clip 16–22 mm	
	Part number: UCW-0523-84-00-00-0
Short rod torch holder with clip 16–22 mm	
	Part number: UCW-0476-27-00-00-0
Short low rod torch holder with clip 16–22 mm	
	Part number: UCW-0476-06-00-00-0
Long rod torch holder with clamp 16–22 mm	
	Part number: UCW-0752-07-00-00-0

Long rod torch holder with clip 16–22 mm	
	Part number: UCW-0466-22-00-00-0
Torch clamp 16–22 mm	
	Part number: ZRZ-0752-07-01-00-0
Torch clip 16–22 mm	
	Part number: ZCS-0476-06-01-00-0
Torch clamp 22–35 mm	
	Part number: ZRZ-0466-19-00-00-0
Short rod	
	Part number: WLK-0476-20-01-00-0
Long rod	
	Part number: WLK-0466-04-10-00-0

4.2. Guide arms


Use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.

4.2.1. Edge following guide arms

Allow guiding the carriage along outside edges.

Install with the included screws.



Adjustment range: 5 45/64" (145 mm).



4.2.2. Adjustable guide arms

Allow guiding the carriage along lap joints and templates.

Adjustment range: 5 45/64" (145 mm).





Part number (2 unit):
PRW-0752-10-00-00-0

4.2.3. Magnet guide arms

Allow guiding the carriage on ceilings.

Adjustment range: 3 15/16" (100 mm).




Part number (2 unit):
PRW-0752-11-00-00-0


4.2.4. Low guide arms

Allow guiding the carriage along low walls.

Adjustment range: 6 11/16" (170 mm).





To put the carriage closer to the workpiece, use the 3 mm hex wrench to remove the roller assemblies. Next, install them at the other end of the guide arms, and then swap the guide arms.




4.2.5. High guide arms

Allow guiding the carriage along walls that have holes.

Adjustment range: 3 15/16" (100 mm).




Part number (2 unit):
PRW-0752-13-00-00-0




4.3. 76 mm cross slide


Increases the up-down or left-right adjustment range from 0–1 3/8" (0-35 mm) to 0–2 63/64" (0-76 mm).



Part number:
ZSP-0466-46-00-00-1




Install in place of the standard cross slide after removing four screws with a 4 mm hex wrench.



4.4. Torch extension arm



Increases the reach of the torch. Use the 4 mm hex wrench to remove the M5x10 screws that attach the cross slide. Next, use the same screws to attach the cross slide at the end of the arm as shown in the figure. Then, use M5x16 screws to attach the arm to the carriage.



4.5. Dual torch mount


Allows using a second torch. Use the 5 mm hex wrench to remove the screws that attach the carrying handle. Next, use the same screws to attach the mount to the carriage.

Part number:
PDT-0466-40-00-00-0



4.6. Auxiliary magnet blocks

The blocks increase the clamping force of the carriage to the surface. Use the 5 mm hex wrench to remove eight screws. Next, install the blocks.



4.7. Flexible guide set

Allows guiding the carriage on planes along a straight line, and on pipes and tanks. A single flexible guide is 6 ft (1.85 m) long. Its minimum curve radius is 3.3 ft (1 m).


Holding force on a 13/64" (5 mm) thick surface		Temperature	
100%	(90 N)	20°C	(68°F)
75%	(68 N)	80°C	(176°F)
50%	(45 N)	120°C	(248°F)






Connect two guides with the 3 mm hex wrench and M5x16 screws to form a butt or lap joint. Next, use the 4 mm hex wrench to remove the standard guide arms and install the new guide arms.

Flexible guide (1 unit):
PRW-0466-50-01-01-0

Butt joint

Lap joint







4.8. Guide adjustment tool

Allows the guide to be put parallel to an outside edge or a groove.

Part number:
UST-0466-53-00-00-0




Attach the magnets to the guide, and put the guide on the workpiece along the direction of welding. Loosen the levers and put the tool onto the first magnet, resting the side of the pilot pin on an outside edge or putting the tip of the pilot pin in a groove. Then, lock the levers in this position and pull the further part of the guide off the workpiece (1). Next, start moving the tool along the guide (2) to clamp the successive magnets to the workpiece.




4.9. Flexible trackway set


Allows the carriage to move on flexible rails that are clamped to planes, pipes, or tanks. A single flexible rail is 6.1 ft (1.88 m) long, and its minimum curve radius is 4.1 ft (1.25 m). Clamp each rail to the surface by using nine narrow magnetic units or at least five magnetic/vacuum units.

Before use, remove the anti-corrosion material from the rail.



Connect two rails with the 3 mm hex wrench (1, 2). Use the 4 mm hex wrench to remove the standard guide arms and install the guide arms of the set with the included screws (3). Remove the sleeve from the long rod (4) and install the rod into the carriage. Next, install the torch holder into the rod (5) and move the rollers outward (6, 7, 8). Then, put the carriage onto the rail and set the rollers as before.






4.10. Magnetic units for flexible trackway

4.10.1. Magnetic unit

Allows clamping a flexible trackway to ferromagnetic surfaces.




Part number:

ZSP-0475-92-00-00-0 (magnetic unit)

ZSP-0475-93-00-00-0 (heat-resistant magnetic unit)


Part number (bracket):

DYS-0466-71-05-00-0



Holding force on a 5 mm (13/64") thick surface	Temperature	
	Magnetic unit	Heat-resistant magnetic unit
100% (1200 N)	68°F (20°C)	68°F (20°C)
75% (900 N)	176°F (80°C)	320°F (160°C)
50% (600 N)	248°F (120°C)	392°F (200°C)

Attach with a torx screwdriver and the 5 mm hex wrench.




4.10.2. Pivoting magnetic unit

Allows clamping a flexible trackway to ferromagnetic surfaces that are concave or convex, to pipes with outer diameters of at least 31 1/2" (800 mm), and to surfaces that differ in height up to 3 5/32" (80 mm).

Part number:
ZSP-0475-85-00-00-0

Part number (bracket):
DYS-0466-71-05-00-0



Holding force on a 5 mm (13/64") thick surface	Temperature	
100% (1200 N)	68°F	(20°C)
75% (900 N)	176°F	(80°C)
50% (600 N)	248°F	(120°C)

Install the unit in the same way as the magnetic unit is installed. To adjust the angle, use the 6 mm hex wrench and loosen four side screws.

4.10.3. Spacing-adjustable magnetic unit


Allows clamping a flexible trackway to two ferromagnetic pipes with diameters of 63/64–9 1/16" (25-230 mm) and with distance between pipe axes of 6 11/16–9 1/16" (170–230 mm).

Part number:

ZSP-0523-19-00-00-0

Part number (bracket):

DYS-0466-71-05-00-0



Holding force on a 13/64" (5 mm) thick surface	Temperature
100% (1200 N)	68°F (20°C)
75% (900 N)	176°F (80°C)
50% (600 N)	248°F (120°C)



Install the unit in the same way as the magnetic unit is installed. To adjust the space, use the 5 mm hex wrench and loosen four side screws.

4.10.4. Narrow magnetic unit

Allows clamping a flexible trackway to ferromagnetic surfaces.


Part number:
PDS-0582-10-00-02-0

Part number (bracket):
DYS-0466-71-07-00-0



Holding force on a 5 mm (13/64") thick surface	Temperature	
100% (1000 N)	68°F	(20°C)
75% (750 N)	176°F	(80°C)
50% (500 N)	248°F	(120°C)

Attach with a torx screwdriver and the 5 mm hex wrench.





To clamp the unit to the surface, use the 17 mm flat wrench and set the side screw to ON.

4.11. Support for flexible trackway with magnetic units

Allows supporting a flexible trackway used with at least five magnetic units, by filling the gaps between the units. To attach the support, use a torx screwdriver and M6x12 screws.

Part number:
WSP-0466-71-06-00-0




4.12. Vacuum unit


When used with a vacuum pump, the vacuum unit allows clamping a flexible trackway to non-ferromagnetic surfaces. The holding force of the vacuum unit is 1400 N at gauge pressure of -0.7 bar (-10 psig) and atmospheric pressure at sea level. The force decreases with increase in height above sea level. To increase the holding force of the trackway, use more vacuum units.

Make sure that the ambient temperature is between -4°F (-20°C) and 392°F (200°C). Keep the flame at least $3\frac{15}{16}$ " (100 mm) away from the vacuum pads.


Part number:
MST-0541-10-02-00-0



Part number (bracket):
DYS-0466-71-04-00-0




Install with a 4 mm hex wrench and 5 mm hex wrench.



4.13. Support for flexible trackway with vacuum units


Allows supporting a flexible trackway used with at least five vacuum units, by filling the gaps between the units. To attach the support, use a torx screwdriver and M6x12 screws.

Part number:
WSP-0466-71-03-00-0



4.14. Vacuum Track System

Allows clamping a flexible trackway to non-ferromagnetic surfaces.




Part number (vacuum pump with safety reservoir):

AGR-0541-24-10-00-0 (115 V US)


AGR-0541-24-20-00-0 (230 V CEE)

Other parts of the system are described in a separate manual.



4.15. Cable anchor

Attaches the gas hoses and the power cable to decrease the load applied on the torch holder. Use the 5 mm hex wrench to install the anchor on the carrying handle.




Part number:

PDT-0466-55-00-00-0

4.16. Display protection shield

Protects the display from dirt. Use the 2.5 mm hex wrench to remove the top screws of the panel and use them to attach the shield.


Part number:
OSL-0466-29-00-00-0



4.17. Fall arrester

Protects the carriage from falling. The length of the line is 33 ft (10 m).


Part number:
URZ-000001




4.18. Stainless steel wheels

Allow working in horizontal position on a preheated plate.

Part number (1 unit):
KOL-0466-72-00-00-0




Use the 2.5 mm hex wrench to remove the cover. Next, remove four wheels using a 3 mm hex wrench. Install in reverse sequence.




5. EXPLODED VIEWS AND PARTS LIST

5.1. Li'l Runner



ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	KBL-0466-17-00-00-0	START-STOP ARC IGNITION CABLE 6.5 M (20 FT)	1
2	KLC-000007	HEX WRENCH 4 MM	1
3	UCW-0466-22-00-00-0	LONG ROD TORCH HOLDER WITH CLIP ASSY	1
4	ZCS-0476-06-01-00-0	TORCH HOLDER CLAMP ASSY	1
5	WLK-0466-04-10-00-0	LONG ROD ASSY	1
6	TLJ-0419-04-02-03-0	INSULATION TUBE	1
7	RKJ-000036	HANDLEVER GN 300-45-M6-32-SW	1




ITEM	PART NUMBER	DESCRIPTION	Q-TY
1	OBD-0752-02-00-00-0	CONTROLLER HOUSING	1
2	WKR-000092	HEX SOCKET BUTTON HEAD SCREW M4x10	4
3	ZLP-000007	KNOB PLUG K11- RED	1
4	PKT-000016	POTENTIOMETER KNOB	1

ITEM	PART NUMBER	DESCRIPTION	Q-TY
5	MSK-0466-02-02-10-1	COVER PLATE ASSY	1
6	USZ-0466-02-02-03-0	COVER PLATE SEAL	1
7	MDL-0752-80-01-00-0	CONTROLLER MODULE	1
8	PDK-000158	EXTERNAL TOOTH LOCK WASHER 3.2	4
9	WKR-000428	CROSS RECESSED PAN HEAD SCREW M3x6	4
10	WZK-0752-02-08-01-0	ARC IGNITION HARNESS	1
11	OSL-000036	LEVER SWITCH COVER	1
12	WZK-0752-02-08-02-0	TRAVEL DIRECTION SWITCH HARNESS	1
13	OSL-000036	LEVER SWITCH COVER	1
14	WZK-0466-02-06-00-0	SUPPLY HARNESS	1
15	MDL-0466-02-03-00-1	PSU MODULE	1
16	PLY-0466-02-08-00-0	INSULATING PLATE	1
17	PKR-0752-02-01-00-0	CONTROLLER COVER ASSY	1
18	NKR-000013	HEX NUT M4	2
19	PDK-000060	EXTERNAL TOOTH LOCK WASHER 4.3	2
20	WKR-000152	CROSS RECESSED COUNTERSUNK HEAD SCREW M4x16	1
21	WKR-000313	HEX SOCKET BUTTON HEAD SCREW M3x8	4
22	NKR-000120	SAFETY NUT	1
23	WZK-0466-02-05-00-0	IGNITION SOCKET WIRE SET	1
24	PNK-000059	POWER SWITCH	1
25	OSL-000219	SWITCH COVER	1
26	PWD-0752-02-04-00-0	POWER CORD 115V	1
27	DLW-000007	CABLE GLAND WITH STRAIN RELIEF PG11	1
28	WKR-000136	HEX SOCKET COUNTERSUNK HEAD SCREW M5x16	4
29	SRB-000075	HEX SOCKET HEAD CAP SCREW M5x10	11
30	SRB-000114	HEX SOCKET HEAD CAP SCREW M6x20	8
31	WSP-0752-04-00-00-0	GUIDE BRACKET	1
32	ZSP-0466-14-00-00-0	CROSS SLIDE ASSY	1
33	NKR-000017	HEX NUT M6	2
34	PKT-0466-14-02-00-0	KNOB	2
35	SPR-000013	DISC SPRING 8,2x18x0,7	4
36	PDK-000022	ROUND WASHER 8.4	2
37	TLJ-000089	SLIDE BUSHING 8x10x1x9,5	2
38	WKR-000026	HEX SOCKET SET SCREW WITH FLAT POINT M5x8	4
39	KLK-000118	DOWEL PIN 8m6x80	4
40	ZSP-0466-99-00-00-1	BOLT SET ASSY	1
41	RKJ-000036	HANDLEVER GN 300-45-M6-32-SW	1
42	KST-0752-06-00-00-0	PLATE BLOCK	1
43	WSP-0752-05-00-00-0	BLOCK BRACKET	1
44	PRW-0752-09-00-00-0	LEFT GUIDE ASSY	1
45	SRB-0466-10-00-00-0	GUIDE ARM SCREW	2
46	SRB-000278	EYE BOLT M6	2
47	PDW-0752-01-00-00-0	CHASSIS	1
48	MTR-0466-01-06-00-0	MOTOREDUCER ASSY	1
49	SRB-000074	HEX SOCKET HEAD CAP SCREW M4x8	5
50	KOL-0752-01-04-00-0	DRIVE WHEEL ASSY	4
51	LOZ-000038	BALL BEARING 12x28x8	4
52	PRS-000005	EXTERNAL RETAINING RING 15z	2
53	KOL-0752-01-06-00-0	GEAR z30	1
54	WLK-0752-01-02-00-0	FRONT SHAFT	1
55	WLK-0752-01-03-00-0	REAR SHAFT	1
56	WPS-000082	PARALLEL KEY 4x4x8	3

ITEM	PART NUMBER	DESCRIPTION	Q-TY
57	KOL-0752-01-05-00-0	GEAR z41	2
58	PRS-000004	EXTERNAL RETAINING RING 14z	2
59	KOL-0752-01-07-00-0	GEAR z=61 ASSY	1
60	WKR-000434	CROSS RECESSED COUNTERSUNK HEAD SCREW M4x20	1
61	PDK-000060	EXTERNAL TOOTH LOCK WASHER 4.3	2
62	NKR-000013	HEX NUT M4	2
63	SRB-000082	HEX SOCKET HEAD CAP SCREW M5x14	4
64	KRP-0752-01-01-00-0	CARRIAGE BODY	1
65	PDK-000108	ROUND WASHER 4.3	1
66	BLO-0752-01-08-00-0	MAGNET BLOCK	1
67	WKR-000130	HEX SOCKET COUNTERSUNK HEAD SCREW M4x10	6
68	OSL-0466-09-00-00-0	WHEEL COVER	1
69	WKR-000091	HEX SOCKET BUTTON HEAD SCREW M4x8	3
70	PRW-0752-08-00-00-0	RIGHT GUIDE ASSY	1
71	SRB-000091	HEX SOCKET HEAD CAP SCREW M5x35	1
72	PDK-000036	ROUND WASHER 5.5	2
73	OSL-0466-06-02-00-0	ROLLER COVER	1
74	RLK-0221-01-19-00-0	ROLLER	1
75	TLJ-0419-06-03-00-0	ROLLER SLEEVE	1
76	TLJ-0456-05-02-00-0	GUIDE ARM SLEEVE	1
77	PRW-0752-08-01-00-0	GUIDE ASSY	1
78	UCW-0752-03-00-00-0	HOLDER	1
79	KLR-000005	SEALING FLANGE 14	1
80	PDK-000098	SILICONE WASHER 20x15	1
81*	WZK-0752-02-02-00-0	POWER SUPPLY WIRE SET	1
82*	PWD-0476-10-00-00-0	GROUNDING WIRE	1

* not shown in the drawing

WIRING DIAGRAM



6. DECLARATION OF CONFORMITY

Declaration of conformity

PROMOTECH sp. z o.o.
ul. Elewatorska 23/1
15-620 Białystok,
Poland

We declare with full responsibility that:

LI'L RUNNER (HS) WELDING CARRIAGE

is manufactured in accordance with the following standards:

- EN ISO 12100:2010
- EN 60204-1:2018
- EN IEC 60974-10:2021

and satisfies the regulations of the guidelines: 2014/30/EU, 2006/42/EC, 2011/65/EU.

Person authorized to compile the technical file:

Wiktor Marek Siergiej, ul. Elewatorska 23/1, 15-620 Białystok, Poland



Białystok, 16 January 2023

Wiktor Marek Siergiej
CEO

7. ENVIRONMENTAL PROTECTION



In accordance with the European Directive 2012/19/EU, this device is marked with the symbol of the crossed-out waste bin. This marking means that the equipment must not be disposed of with other household waste after the service life. The user must return the product to a collection point for used electrical and electronic equipment. The collectors of used equipment, including local collection points, shops and municipal units create an appropriate system for returning such equipment. Correct handling of used electrical and electronic equipment helps in avoiding damage to health and the environment, which may result from the presence of dangerous components and incorrect storage and processing of such equipment.

8. WARRANTY CARD

WARRANTY CARD No.....

..... in the name of Manufacturer warrants the LI'L RUNNER (HS) Welding Carriage to be free of defects in material and workmanship under normal use for a period of 12 months from the date of sale.

This warranty does not cover wheels as well as damage or wear that arise from misuse, accident, tampering, or any other causes not related to defects in workmanship or material.

Serial number

Date of sale

Signature and stamp of the seller

0.06 / 8 February 2024

WE RESERVE THE RIGHT TO MAKE CHANGES IN THIS MANUAL WITHOUT NOTICE